# GUY WIRE **MARKER** MANUAL INSTALLATION



## SUPPLIES

- Bird Flight Diverter
- Retention clip, included
- Adjustable pliers, not included



#### INSTRUCTIONS



Flex the marker and place it over the wire.



Push the marker over the wire in a downwards motion until it snaps into place.



Place the retention clip around the wire underneath the marker and pre-engage by hand.



Tighten the clip with adjustable pliers.

## NOTE

To remove, separate clip engagement from female side.

## VIDEO TUTORIAL

Scan the QR code to see a quick video of a live install > Or visit powerlinesentry.com/install-support for a full library of support materials.





TRUE POWER RELIABILITY DEMANDS EFFECTIVE WILDLIFE PROTECTION POWERLINESENTRY.COM | INFO@POWERLINESENTRY.COM | 970.599.1050