BUSHING COVER HOTSTICK INSTALLATION



SUPPLIES

- Bushing cover, BC-D01, featured here
- Hotstick (not included)

INSTRUCTIONS



Hook and lock the hotstick through the eye screw.



Position the bushing cover into place over the engergized equipment.



Adjust the fit by turning the eye screw clockwise until a tight fit has been achieved.



Installation is complete once the fit is confimed to be tight.

VIDEO TUTORIAL

Scan the QR code to see a quick video of a live install > Or visit powerlinesentry.com/install-support for a full library of support materials.





TRUE POWER RELIABILITY DEMANDS EFFECTIVE WILDLIFE PROTECTION POWERLINESENTRY.COM | INFO@POWERLINESENTRY.COM | 970.599.1050